


**INFORMATION:** All pieces, **EXCEPT THE FRONT COVER AND JUICE CONTAINER**, can be cleaned in a dishwasher. The juice extraction zone and the front cover should be cleaned using a moist cloth and dish washing liquid. Rinse with clean water to remove any washing liquid traces.



**11.** Replace the dismantled pieces by the cleaning kit pieces.



**12.** Mount the pressing units by pairs.



**13.** Fix the knobs and tighten them well. Missing knobs are to be replaced immediately. Never operate the machine with any knob missing.



**14.** Put on the peel ejectors. Push them firmly to assure their right positioning in order to avoid breakage while using the machine.



**15.** Put on the knife. Push until it clicks into place with a "click".



**16.** Mount the tap.



**17.** Put on the front cover.



**18.** Insert the juice tray and the filter.



**19.** Place the peel buckets.



**20.** Place the glass holder tray and the filter.

REF: 235.0030.000

**CAUTION!** Make sure machine is unplugged from electrical current. For a correct cleaning process please follow the instructions below.



**1.** Take out the juice tray and the filter.  
Be careful not to lose the filter.



**2.** Take out the peel buckets.



**3.** Take off the front cover.



**4.** Extract the knife by pulling it towards you.  
**CAUTION!** The blade is very sharp, be careful not to cut yourself.



**5.** Pull off the peel ejectors.



**6.** Unscrew the securing knobs of the pressing unit.



**7.** Take of the pressing units in pairs.



**8.** Remove the tap.



**9.** Take of the glass holder tray and the filter.



**10.** In case of podium models, clean the chute and the inside of the podium to remove all traces of peel and pulp.